Boiler Control Replacement Parts



Combination Low Water Cut-Off/Pump Controllers For Steam Boilers

Series 42 and 42SLow Water Cut-Off/Pump Controllers



Series 42S

Replacement Head Mechanisms


For	Repl. Head	Part	Description	Weight
Model	Model No.	Number		lbs. (kg)
42S	42S-HD	129502	Head mechanism	7.5 (3.4)

Head mechanisms include a gasket and bolts.

Components (shown on page 19)

ltem Number	Part Number	Model Number	Description	Weight lbs. (kg)
1	302700	CO-12	Head gasket (25 pack)	0.1 (.05)
2*	328300	MA-159	Quick hook-up fittings (includes items 4, 5, 6)	6.0 (2.7)
3*	351800	SA259-24	Upper quick hook-up fittings	1.7 (.77)
4*	349500	SA159-24	Lower quick hook-up fittings	1.7 (.77)
5*	349400	SA159-17	Black "Y" assembly	3.0 (1.4)
6	347900	SA150-106R	Bellows Assembly	0.4 (.18)

Model 42S-A



Model 42S-HD


Replacement Switch Information

IMPORTANT:

- · Snap switches must be replaced as an assembly.
- We recommend complete head replacement to eliminate the need for field replacement of the switch assembly.
- Series 42 & 42S Replacement Switch Assemblies are not interchangeable and must be selected and ordered for the specific control model(s) on which they will be installed.

Replacement Switch Assemblies For Series 42S

For	Repl. Switch	Part	Description	Weight
Model	Model No.	Number		lbs. (kg)
42S	SWA-42S	310488	Snap-action switch assembly	0.5 (.23)



Model SWA-42S

^{*} Available for 42S-A models only.

Boiler Control Replacement Parts



Combination Low Water Cut-Off/Pump Controllers For Steam Boilers

Series 42 and 42S (continued)
Low Water Cut-Off/Pump Controllers

Components

