


1.4 Air/Gas/Oil Sensors



Air Pressure Sensor

Item No.	Mk8 Air & Gas Sensors	Kgs	Part No.
22	Air Pressure Sensor Analogue: 0 to 65mbar, 0 to 25"wg, 0 to 1 PSI – when used with Mk7 MM Digital: -68 to 68mbar, -27 to 27"wg, -1 to 1 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80005
23	Air Pressure Sensor Analogue: 0 to 130mbar, 0 to 50"wg, 0 to 2 PSI – when used with Mk7 MM Digital: -137 to 137 mbar, -55 to 55"wg, -2 to 2 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80013
24	Gas Pressure Sensor Analogue: 12.5 to 65mbar, 5 to 25"wg, 0.18 to 1PSI – when used with Mk7 MM Digital: -68 to 68mbar, -27 to -27"wg, -1 to 1 PSI – when used Mk8 MM and Mini Mk8 MM	0.42	MM80006
25	Gas Pressure Sensor Analogue: 52 to 340mbar, 25 to 135"wg, 0.75 to 5 PSI – when used with Mk7 MM Digital: -344 to 344mbar, -138 to 138"wg, -5 to 5 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80008
26	Gas Pressure Sensor Analogue: 115 to 750mbar, 50 to 300"wg, 1.8 to 11 PSI – when used with Mk7 MM Digital: -1034 to 1034mbar, -415 to 415"wg, -15 to 15 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80011
27	Gas Pressure Sensor Analogue: 207 to 1380mbar, 83 to 550"wg, 3 to 20 PSI – when used with Mk7 MM Digital: -2068 to 2068mbar, -831 to 831"wg, -30 to 30 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80012
28	Gas Pressure Sensor Analogue: 400 to 6000mbar, 166 to 2767"wg, 6 to 100 PSI – when used with Mk7 MM Digital: -6894 to 6894mbar, -2770 to 2770"wg, -100 to 100 PSI – when used with Mk8 MM and Mini Mk8 MM	0.42	MM80014
29	Flying Lead for Gas & Air Sensor Replacement Flying Leads for Gas & Air Sensors, Length 2m (6ft)	0.05	AUTO/0005
30	Flying Lead for Gas & Air Sensor Replacement Flying Leads for Gas & Air Sensors, Length 10m (32ft)	0.05	AUTO/0005/10
Mk8 Air & Gas Sensors are suitable for usage with Mk8, Mk7 and Mk6 modules			

1 MM Control Modules & Parts



Oil Pressure Sensor

Item No.	Oil Sensor	Kgs	Part No.
31	Oil Pressure Sensor 0 to 40 Bar, 0 to 600 PSI	0.42	MM60009